



PRT Flex Stripper

EXTREME PERFORMANCE STRIPPING AGENT

DESCRIPTION

VPI PRT Flex Stripper is specially formulated to remove VPI PRT Flex Shield. It quickly liquefies and lifts VPI PRT Flex Shield, soils, and other impurities left behind on the floor. Once rinsed, VPI PRT tile is again ready for recoating with VPI PRT Flex Shield.

USES / BENEFITS

- **Extremely economical to use**
- **Highly Concentrated**
- **Biodegradable**
- **Environmentally Safe**
- **Preps and conditions tile**
- **Meets or exceeds National Green standards for floor care**
- **Can be used by mopping, or in auto scrubbers**
- **Rapidly dissolves Flex Shield**
- **Leaves no residue**
- **Works fantastic on PRT**

DIRECTIONS FOR USE

Sweep or dust mop the floor to remove any large debris. Never use oil base treated dust mops. Dilute VPI PRT Flex Stripper (1 part stripper : 5 parts fresh water) or 25.6 oz./gal with cool to warm water. Liberally apply solution to floor surface. Allow 4 - 5 minutes contact time. Be sure to keep surface wet at all times.

Using the VPI Initial Deep Scrub Pad (gray in color), agitate floor thoroughly with a low-speed rotary machine, or automatic scrubber. Pick up the solution with a wet vacuum, automatic scrubber, or a mop and bucket. Rinse with clear water only.

Allow floor to dry completely before applying VPI PRT Flex Shield according to label directions.

NOTE: It is very important to follow the specific directions for cleaning VPI PRT TILE. Treating it otherwise, can negatively impact visual appearance. IMPORTANT: Never buff in excess of 375 RPM.

SPECIFICATIONS

ColorWater White
 Fragrance Mild
 pH conc.11.0
 pH in dilution10.0
 Residue None
 BiodegradableYes
 Coverage.....2,000 sq ft per gallon

PRECAUTIONS

KEEP OUT OF REACH OF CHILDREN.
 See container and MSDS for further safety instructions.

PRT Earthtones, simply the most durable & beautiful commercial floor on the market today.....