



PRT Initial Deep Scrub Cleaner

EXTREME PERFORMANCE PREPARATORY AGENT

DESCRIPTION

PRT Initial Deep Scrub Cleaner is the first step in the overall VPI PRT Flooring Initial Maintenance System. PRT Initial Deep Scrub Cleaner meets or exceeds green industry standards for floor care products based on its reduced levels of volatile organic compounds, biodegradability, and low toxicity.

Used in conjunction with the VPI Initial Deep Scrub Pad (gray in color) it deep cleans, preps, and conditions any new VPI PRT tile floor by thoroughly removing deep down manufacturing residue and ground in installation debris.

Deep scrub cleaning, using VPI PRT Initial Deep Scrub Cleaner is required before cleaning the surface of the floor.

USES / BENEFITS

- **Extremely economical to use**
- **Highly Concentrated**
- **Biodegradable**
- **Environmentally Safe**
- **Preps and conditions tile**
- **Meets or exceeds National Green standards for floor care**
- **Can be used by mopping, or in auto scrubbers**
- **Leaves no residue**
- **Works fantastic on PRT**

SPECIFICATIONS

Color	Water White
Fragrance	Mild
pH conc.	11.0
pH in dilution	10.0
Residue	None
Biodegradable	Yes
Coverage.....	4,000 sq ft per gallon

PRECAUTIONS

KEEP OUT OF REACH OF CHILDREN.
See container and MSDS for further safety instructions.

DIRECTIONS FOR USE

For newly installed VPI PRT tile, sweep or dust mop the floor to remove any large debris. Never use oil base treated dust mops. (See **VPI PRT CLEANER** instructions for how to clean previously installed VPI PRT tile).

Dilute **VPI PRT Initial Deep Scrub Cleaner** (1 part cleaner : 10 parts water) or 13 oz./gal with cool clean water and apply liberally to the floor. Using the **VPI Initial Deep Scrub Pad (gray in color)**, agitate floor thoroughly with a low-speed rotary machine or automatic scrubber. Approximately 5 passes are required to properly deep scrub the floor. Make sure floor remains very wet.

Pick up the solution with a wet vacuum, automatic scrubber, or a mop and bucket. Rinse with clear water only. Allow floor to dry completely before starting the surface cleaning process using **VPI PRT Initial Surface Cleaner** in conjunction with **VPI Initial Surface Cleaning Pads** per VPI's written instructions.

NOTE: It is very important to follow the specific directions for cleaning VPI PRT TILE. Treating it otherwise, can negatively impact visual appearance. IMPORTANT: Never buff in excess of 375 RPM.

PRT Earthtones, simply the most durable & beautiful commercial floor on the market today.....



Toll Free: 800-874-4240

www.vpiflooring.com VPI Corporation